Lifestyle®
appliances limited

LFBG-100AP – 102AP Navarra Chair Instructions

Thank you for Purchasing this Lifestyle Product

- Please retain these instructions for your records. They will assist you in utilizing your purchase safely and maintaining it in optimal condition.

- Due to the presence of moving joints, it is advised that children be always supervised while utilizing the Chair and should avoid opening or closing it.

- When operating the Chair, avoid applying excessive force when opening and closing it. The Chair is designed to open and close smoothly without the need for force.

General Use

- Ensure that the Chair is positioned on a flat surface to minimize the risk of tipping.
- Ensure that the Locking Arms are securely locked into place prior to utilizing the Chair To prevent entrapment Ensure that fingers are kept clear of the Joints when opening and closing the Chair.
- Avoid leaving the Chair outside in severe weather conditions, as this may lead to damage or cause injury during high winds.

Operating the Chair

To unfold the chair, position it upright on its legs. Stand beside the chair and ensure that the arms are not obstructed by the Arm locking mechanisms. Apply downward pressure on the arms while simultaneously pushing backward on the backrest (this will be in the opposite direction and will facilitate the opening of the frame.)

The Frame is in the correct position when the back leg is located into the black bracket on the back of the chair.

At this stage, the chair will appear as follows: lift the arms so that they are no longer in the locking positions. Position your foot behind one of the rear legs, which will allow you to pull the backrest into an upright position. When you are prepared to adjust the chair while seated, lift the arms and gently lean back; this will enable you to modify the backrest to your desired position. Once you have achieved the desired position, secure the arms by pushing them down into the locking position.

This Chair has an adjustable head rest which can be adjusted to the required position by simply moving it up and down.

To Fold the Chair, Ensure that the arms are free from the locating position by gently lifting them. Stand beside the chair and carefully pull the backrest while simultaneously lifting the seat portion of the chair. You will be bringing the backrest and seat portion together; once both are nearly aligned, gently push in line with the arms, and the frame should close together. The chair is now closed.

Note Transform any chair into a lounger using the Calella stool. Designed with superior quality, the Calella is engineered for effortless use. Its lightweight structure allows for easy movement and handling, making it perfect for transport with its convenient folding capabilities and straightforward storage. Plus, with its quick-drying material, you need not fret about unexpected rain showers. Contact your retailer, inquire about the Lifestyle Furniture Carry Bag LFBG-112 or LFBG-112G.

Warning The Chair is intended for use by one individual at a time. Standing on the Chair is prohibited.

Storage

To maintain the appearance of your product for an extended duration and to prolong its lifespan, we advise that the product be covered when it is not in use. If the product will not be utilized for a significant period, we suggest that it be properly folded and stored in a clean, dry, and moisture-free location.

Note Prolong the lifespan of your furniture with the durable Navarra Furniture Carry Bag. Designed for universal application, it offers a more convenient and secure way to store and transport your belongings. With its ample capacity, the bag can easily accommodate several chairs. It features an extended opening and dual zippers for hassle-free operation. Contact your retailer, inquire about the Lifestyle Furniture Carry Bag LFBG-117.

Care and Cleaning Instructions

Avoid using harsh or abrasive cleaners or brushes when cleaning this product, as they may damage the frame and fabric. Do not fold and store the product while it is wet, as this could result in the formation of mould or mildew on the product. • Fabric: We suggest using simply warm soapy water. After cleaning, rinse thoroughly and let the product dry naturally. • Frame: First, let any dirt dry and then brush it off with a soft cloth to eliminate loose dirt. Wipe the frame with warm soapy water using a soft cloth. After cleaning, allow it to dry naturally.

Warranty

In the rare instance of a warranty claim, it is essential to reach out to the retailer from whom you made the purchase, along with your proof of purchase.

- The retailer will examine the product and communicate with Lifestyle regarding any claims.
- You will be kept updated by the retailer on the status of the claim.
- Lifestyle will not contact you directly (except in exceptional circumstances) as all information will be relayed back to your retailer.

This product is accompanied by a comprehensive 24-month warranty against manufacturing defects, which covers any such defects for a period of two (2) years from the date of the original purchase.

It does not cover any damage that occurs due to: • The product being dropped or subjected to accidental damage.

- Any technical modifications made by the owner or a third party.
- Improper usage of the product.
- Normal wear and tear, which includes (but is not limited to) colour fading, wearing, and stretching.
- Damage resulting from failure to adhere to the instruction manual will void the warranty; if this leads to consequential damages, Lifestyle will not be responsible for these damages or any associated costs.
- Lifestyle will not be liable for material damage or personal injury resulting from improper use or failure to fully execute safety instructions.
- All claims must be submitted through the retailer from whom the product was purchased .
- Warranty claims cannot be honoured without an original dated receipt or proof of purchase.
- Undertaking repairs will not extend the original warranty period of two (2) years, nor will it grant a new warranty.