



Instructions

LFS703

Signa Fire Basket

- For Outdoor Use Only, do not use indoor for cooking or heating. Always operate in an open well ventilated area.
- Do not use petrol, kerosene or lighter fuels or flammable fluids to ignite fire, only use methods of ignition which are acceptable in accordance with your local fire safety codes
- Failure to read and observe all warnings, directions of use and extinguishing, may result in unsafe conditions leading to damage to property, or injury.
- Do not use alcohol, intoxicants, narcotics, or any form of non-prescription drug when handling the fireplace, as the ability to safely assemble and operate the product will be impaired.
- Never operate in an enclosed space such as house, garage, trailer, tent, caravan, building or under overhead construction.
- Do not use this outdoor fireplace near any type of vehicle. This fireplace should never be used in or on boats or recreational vehicles.
- Do not operate under hanging trees or near shrubs, a burning fireplace must be kept at a distance of at least 3-4 meters from any building or flammable material to ensure no fire related damages are caused.
- Do not use in windy or extremely windy conditions
- Do not use near electrical cords or appliances
- Do not place on combustible surfaces, or wooden decking.
- Only use on level, hard standing & non-combustible surfaces.
- When burning a fire, keep it small, do not over fill, only add wood in small amounts and only add wood on to the log grate.
- Never move or handle the fireplace while in use. Do not touch surfaces as they will be hot.
- Never leave open flames or burning embers unattended. Spark screens must be kept in place on the fireplace during use to prevent the spread of fire.
- Fireplace will remain very hot for a long time after use. Be sure fireplace has cooled before moving.
- Always inspect for signs of damage before use, do not use until correct repairs have been made.
- Do not allow children to use the Fireplace. Keep children, pets and the elderly away from the hot fireplace.
- Always keep fire suppression tools nearby, use protective gloves and long handled tools for use with the fireplace.
- Use care when working near fire, do not stand over the fireplace when lighting or during use, loose clothing can catch fire easily, always wear suitable clothing.
- Make sure the ashes are disposed of after each use & only after the unit & ashes have completely cooled.
- Failure to follow all instructions or warnings could result in serious injury and/or property damage.
- Follow all local or national fire codes when using the unit. Contact your local fire department for information on outdoor burning regulations.

